

20250101-051202




FIG. 1

This exploded perspective view illustrates the assembly of the portable electronic device. The components are labeled as follows:

- 33**: The top cover or display panel.
- 32a** and **32b**: The front and back bezels or side plates.
- 34a** and **34b**: The front and back side plates or flaps.
- 30a** and **30b**: The front and back main housing or frame components.
- 46**: A central component, likely the display or screen, mounted on a frame.
- 18**: A hinge or pivot mechanism connecting the side plates to the main housing.
- 44**: A sliding mechanism or guide rail for the side plates.
- 50**: A component, possibly a speaker or microphone, located within the housing.
- 20**: A component, possibly a camera or sensor, located within the housing.
- 38**: A base plate or support structure.
- 12**: A bottom cover or base plate.
- 35**: A component, possibly a battery or power source, located within the base.
- 36b**: A side plate or flap on the bottom cover.
- 48**: A circular component, possibly a lens or a port, located at the bottom of the device.

FIG. 2

202790-061202




FIG. 3




FIG. 4





FIG. 5

10066310 061202



TC NOS.	LOCATION
1-3	ON BOTTOM FACE OF WOOD JOIST BETWEEN WOOD JOIST AND WALLBOARD
4-15	ON WOOD JOIST FACE AT MIDHEIGHT
16-21	ON UNDERSIDE OF PLYWOOD FLOORING
22-30	ON FIXTURE WITHIN JOIST CAVITY
31-36	ON UNEXPOSED SURFACE

THERMOCOUPLE LOCATIONS

FIG. 6




FIG. 7




FIG. 8

FIG. 9





FIG. 10






FIG. 11




FIG. 12